



NEWISYS®
A SANMINA-SCI COMPANY

REVISION HISTORY				
Rev	Date	Description	ECO#	Changed By
A-01	6/14/06	Initial Release	A-001171	J. Jenne

1.0 Overview

This document outlines the instructions for applying the software patch S06702 that is part of the Software Patch Kit S06700.

2.0 OEM/Reseller Support Web-site Setup

1. Download the file "S06702-A01_Keystone_5.4.0-162+RTC_web-update.zip" from the Newisys Support Site.
2. Unzip the file in to the document root of your support web server. You may unzip files in to a subdirectory, but this subdirectory will have to be specified in the following steps.
3. Test access to this new folder using the Web browser. The path should look like
<http://web-server>
<http://web-server/subdirectory>

The following information is extracted from the NA-1400 User Guide and is provided as a reference.

3.0 NA-1400 Web Update

1. NA-1400 should be connected to a LAN with access to the internet.
2. Boot NA-1400.
3. Login to management GUI
4. Go to Maintenance->Update
5. Fill in the address box of the "Repository" section with the address for the OEM/Reseller support Web-server
web-server
web-server/subdirectory

The screenshot shows the Newisys Management GUI. At the top, there are navigation tabs: Administration, Date/Time, Backup, Update (selected), and Troubleshooting. A Help link is visible on the right. On the left, a sidebar contains icons for Status, Folders & Sharing, Storage, Maintenance (selected), Networking, Security, Logoff Appliance, and Shutdown Appliance. The main content area is titled 'Update' and contains two sections: 'Repository' and 'Proxy settings'. The 'Repository' section has three input fields: Address, Login, and Password. The 'Proxy settings' section has four input fields: Address, Port, Login, and Password, followed by a 'Use proxy' checkbox. Below these sections is a 'Progress' bar showing '0% completed' and an 'Accept' button. At the bottom left of the GUI is the 'Java Powered' logo.

S06701: NA-1400 Software Patch Kit Instructions, Release 5.4.0-162

Rev. A-01

Date: 06/14/06

Sheet 3 of 3

6. If the OEM/Reseller has set up any authentication required for access to their Web-server, fill in the required login and password. Otherwise leave these fields blank.
7. If internet access requires a proxy server, fill in the required information. Otherwise leave these fields blank.
8. Click on accept.
9. The NA-1400 will connect to the OEM/Reseller website. If an update is needed, the NA-1400 will download the software update and install it. Otherwise, it indicates that no update is needed.

Download complete. No files to update.

OK

10. The web browser will auto-refresh every 5 seconds and provide some progress information.

Note: If the web browser does not auto-refresh, you may have to change the security settings for the web browser. It is recommended that that Reseller/OEM support site be added to the list of trusted sites.

Administration | Date/Time | Backup | Update | Troubleshooting | Help

NEWISYS
A SANMINA-SCI COMPANY

✓ Status
Folders & Sharing
Storage
Maintenance
Networking
Security

Logoff Appliance
Shutdown Appliance

Repository
Address: 192.168.0.55/5.4.0/rc2
Login:
Password:

Proxy settings
Address:
Port:
Login:
Password:
Use proxy:

Progress
85% completed

Accept

Java
POWERED

ApplianceWare

11. When the web update has completed, a success message is displayed. The NA-1400 is then rebooted with the new software update installed.
12. After the NA-1400 has booted, it is ready for use.